

# Titan Remote Control Layout

## Setup

Use for all programming sequences.

## Skip Back

Instantly replay the last 7 seconds of the program you are watching.

## Playback Control

Control playback of video or audio files relating to DVR/PVR, DVD, VCR or CD devices.

## Guide

Display the program guide.

## Menu

Display the options menu of the home theatre device you are controlling.

## Day + /Day -

Move a day forward (or back) on your program guide.

## OK

Enter a choice you have made.

## Vol + /Vol -

Adjust Volume

## On Demand

Direct Access to On Demand programming. (Available with IPTV only).

## Mute

Turn sound on or off.

## Fav

Cycle through your favorite channels stored on your STB.

## Number Pad

Enter a channel number.

## Input

View other video sources.

## Macro Keys

Customized by you or your service provider.

## Power

Turn a selected device on or off.

## Device Selection

Press once to select a home entertainment device to control.

## List

Display a list of recorded programming on your DVR/PVR.

## Live

Return to watching Live TV.

## Exit

Directly exit menus, guides and applications.

## Info

Display the current channel & program information.

## Page + /Page -

Page up or down through menu screens and the program guide.

## Cursor Keys

Move the cursor in the program guide and menu screens.

## Shortcuts

A, B, C or D are shortcuts to access additional features.

## CH + /CH -

Change the channel.

## Last

Return to previous channel.

## Closed Captioning

Turn closed captions on or off.

